


PIEZO FEEDER SIZE



	A	B	C	D	E	F	G	H	I	J	K	L	O	Q	R	図番号	
PEF-90A	90	100	100	50			175	80					M6	—	—	—	1
PEF-120A	120	130	115				205	110									
PEF-150A	150	160	137		2.3	15	225	130	10		7	M8	4-M5	4.5	16	2	
PEF-190A	190	210	187				290	180									35
PEF-230A	230	260	205				330	220									
PEF-300A	300	320	225		3.2	19	414	270	45	15		M12	3-M8	6	19	3	
PEF-390B	390	440	252				534	380	50								
PEF-460B	460	530	304				645	465	60								
					4.5	25					10	M16	4-M10		25		

(単位：mm)